This Page Is Inserted by IFW Operations and is not a part of the Official Record

BEST AVAILABLE IMAGES

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

IMAGES ARE BEST AVAILABLE COPY.

As rescanning documents will not correct images, please do not report the images to the Image Problem Mailbox.

WATER-COOLED ENGINE CONTROL

CROSS-REFERENCE TO RELATED APPLICATIONS

This application claims the benefit of U.S. Provisional Patent Application serial number 60/109,716 filed November 24, 1998.

BACKGROUND OF THE INVENTION

This invention relates generally to combustion engines and, more particularly, to electronic control units for such engines.

5. Known combustion engines for use with watercraft include an air-cooled electronic control units (ECU) for controlling at least some operations of the engine. With increased processing demand and an increase in the number of ECU electronic components, a need has developed for improved cooling as compared to the cooling provided by the known air cooling configurations. In addition, with known ECU configurations, testing of the ignition coils has been limited to transmitting commands to cause such coils to fire without verification as to whether the coils actually did fire.

BRIEF SUMMARY OF THE INVENTION

15

It would be desirable to increase the amount of circuitry in the ECU to include heat-generating circuitry without the generated heat causing the ECU to malfunction. It would also be useful to allow the ECU to check the ignition coils and determine whether or not they are operational.

One embodiment provides a water cooled ECU in order to allow more electrical components to be present in the ECU. The ECU also is able to not only cause the ignition coils to fire, but also to verify whether such coils did, in fact, fire.

A water-cooled configuration for the ECU provides enhanced cooling as compared to known air-cooled configurations. The water-cooled ECU is configured to contain portions of the ignition circuit, which has previously been outside the ECU.

BRIEF DESCRIPTION OF THE DRAWINGS

Figure 1 is a top front perspective view of a marine outboard combustion engine, incorporating a preferred embodiment of the invention;

Figure 2 is a top rear perspective view of the engine of Figure 1;

Figure 3 is a top, left, rear perspective view of an electronic control unit for use with the engine of Figure 1;

Figure 4 is a top external view of the ECU of Figure 3;

Figure 5 is a front elevational external view of the ECU of Figure 4;

Figure 6 is a bottom view in cross-section taken along lines 6-6 of Figure 5;

Figure 7 is a side external view of the forward connector of the ECU of Figures 3-6, taken along lines 7-7 of Figure 4;

Figure 8 is an external view of the rear connector of the ECU of Figures 3-6 taken along lines 8-8 of Figure 5 and lines 7-7 of Figure 6;

Figure 9 is a block diagram illustrating the information flow through the ECU of Figures 3-6;

Figure 10 is a block diagram illustrating a power distribution panel for the ECU of Figures 3-6;

Figure 11 is a block diagram of the sensor and circuit switch module of the ECU of Figures 3-6;

10

15

20

25

Figure 12 is a block diagram of the ignition circuit of the ECU of Figures 3-6 for a four-cylinder engine;

Figure 13 is a block diagram of the ignition circuit of the ECU of Figures 3-6 for a six-cylinder engine;

Figure 14 is a block diagram of a fuel injector circuit for a four-cylinder engine, showing the connections to the ECU of Figures 3-6;

Figure 15 is a block diagram of a fuel injector circuit for a six-cylinder engine, showing the connections to the ECU of Figures 3-6;

Figure 16 is a left, front, top exterior exploded perspective view in partial cutaway to show the cooling water flow through a marine outboard engine adapted for use with the ECU of Figures 1-3;

Figure 17 is a flow diagram showing how the coolant flow system of Figure 16 is connected to the ECU of Figures 1-3; and

Figure 18 is a schematic drawing of the electric wiring for the marine engine of Figures 1-2 showing how the main engine parts are electrically connected.

DETAILED DESCRIPTION OF THE INVENTION

Figure 1 is a top front perspective view of an electronic control unit (ECU) 100 connected to a marine outboard combustion engine 101. Unit 100 is located in a powerhead 102. Powerhead 102 also contains a flywheel cover 103 and a capacitor 104. It will be understood that this location of ECU 100 is exemplary and ECU 100 could be located anywhere that is practical and desired on engine 101. ECU 100 includes a water-cooled (in a manner described below) housing containing a microprocessor that receives sensor, switch and electrical signals and power that provides information on engine operating conditions in powerhead 102, interprets those signals, and generates commands to the various components that are connected to ECU 100. In addition to controlling engine operation, ECU 100 has a number of

10

15

20

25

other important programmed functions. ECU 100 stores service codes, activates a warning system, provides choke-less cold starting, controls engine monitoring gauge lights, generates a tachometer signal, prevents excessive engine RPM, provides an initial break-in oil ratio that is twice normal rate, controls electric fuel pump operation, and records engine operating hours. ECU 100 is an EEPROM design, so service codes will not be lost if battery power to ECU 100 is lost. Stored service codes that have not reoccurred for 15 or more running hours will automatically be eliminated from memory.

A crankshaft position sensor 106 is located on a first side of powerhead 102, and a throttle position sensor 108 and starter solenoid 110 are located on a second side of powerhead 102. In addition, timing pointers 112 and 114 are on flywheel cover 103 for purposes of timing, respectively, the four cylinder and the six cylinder version of engine 100.

Figure 2 is a top, rear, perspective view of marine outboard combustion engine 100. In Figure 2, ECU 100 is mounted adjacent capacitor 104 and above and behind flywheel cover 103, although, as stated above, this position could be anywhere that is desired. ECU 100 has two electrical harness connectors, a forward connector 116, and a rear connector 118. Engine 101 also includes a main power relay 120, a water temperature switch 122 and a water temperature sensor 126. A vapor separator vent hose 124 leads to a vapor separator (not shown). A water hose 128 from the vapor separator wraps around ECU 100. Several fuel hoses 130 are connected to a fuel junction block 132. Engine 100 has a throttle position sensor 108 used to determine the actual throttle position.

Figure 3 is a perspective view of ECU 100. A water passage 134 is disposed in heat transfer adjacency to a portion of ECU 100. Water passage 134 has a water hose connector 136, 138 at either end, and serves as a heat exchanger to cool ECU 100 by transferring heat from ECU 100 into water flowing through water passage 134. Water passageway 134 lies horizontal, but could be oriented vertically, if desired.

The flow through passageway 134 could be driven by a water pump or could be by convection, since hot water naturally rises and cold water settles. Convection flow, which occurs naturally in response to heating of water makes the coolant flow more dependable since it depends solely on physical principles without moving parts. Pump driven flow is likely to be at higher flow rates and thus able to cool more effectively, but is more likely to be subject to mechanical breakdown. Which is used depends on the amount of cooling needed.

In addition to sensors (described below) located outside of ECU 100, any desired number of sensors 139 are located inside ECU 100. Sensors 139 can be conventional sensors. Sensors 139 can, by way of example, be sensors for barometric pressure, control unit temperature, alternator voltage (26 volts), battery voltage (12 volts), and ROM verification.

The barometric pressure sensor is a silicon pressure sensor having diaphragm-sealed air passages that generates an alternating current voltage signal. It senses ambient air pressure through a screened port that is open to atmosphere. The barometric pressure signal enables ECU 100 to compensate for changes in altitude and air density up to 14,000 feet (4267m) so it can adjust fuel flow accordingly. If sensed values are out of limits, or the sensor or circuit fails, ECU 100 will turn on a "CHECK ENGINE" light, and store a service code.

20

5

10

15

ECU 100 temperature sensor, also inside ECU 100, monitors fuel injector driver circuit temperature to prevent that circuitry from exceeding design limits. One or more fuel injectors could malfunction should this occur. If sensor values are out of limits, or the sensor circuit fails, ECU 100 will turn on the "CHECK ENGINE" light, and store a service code. ECU 100 will also initiate a special "SLOW" warning system, but only if excessive temperature is the failure mode.

25

The 26-volt circuit sensor monitors the rectifier/regulator 26-volt output. This is the circuit the powers the field injectors. If voltage exceeds the expected range, ECU 100 will initiate "SLOW", store a service code, and turn on the "CHECK

15

20

25

ENGINE" light. Voltage below the expected range will store a service code and turn on the "CHECK ENGINE" light, but will not put engine 101 into "SLOW".

The RPM limiter feature of ECU 100 programming prevents engine damage due to excessive engine speed. At 6116 RPM, fuel and ignition to even numbered cylinders are shut off. At 6144 RPM, fuel and ignition to the remaining cylinders are also shut off. Normal operation returns automatically as soon as engine speed drops down to the specified range, in this case below 6116 RPM.

The idle governor reacts to water temperature sensor values. It changes fuel pulse width to maintain engine speed within a range of 650 RPM (warm engine) to _____about 850 RPM (cold engine). The governor is inactive above about 1200 rpm. ____

The 12-volt circuit sensor monitors rectifier/regulator 12-volt output. This is the circuit that supplies all 12-volt components/circuit requirements. If voltage is out of limits, high or low, ECU 100 will store a service code and turn on the "CHECK ENGINE" light.

The ROM verification sensor is a continual ECU self-test of factory programming. ECU 100 will turn on the "CHECK ENGINE" light and store a service code if, at any time, a program failure is detected.

Figures 4-5 are top and front views of ECU 100. Water passage 134 is enclosed in a metallic housing 140 that has a rounded top 144 and a flat bottom 146 adapted to fit atop a flat top surface 142 of ECU 100 for good heat transfer.

Figure 6 is a top plan view in cross-section taken along lines 6-6 of Figure 5, illustrating the circuitry within the ECU 100. The circuitry is divided into a low-power portion 148 and a high-powered portion 150. It will be understood that high-powered portion 150 is in heat transfer adjacency to the water passage 134 so that the primary sources of heat generated by and within ECU 100 all are in heat transfer adjacency to water passage 134. Placement of water passage 134 directly on top of ECU 100 and in heat transfer adjacency to high-powered portions of electronic

10

15

20

25

circuitry enables high-powered electrical circuitry to be more compactly and densely placed within ECU 100. As electrical circuitry becomes more and more sophisticated, cooling of ECU 100 becomes more and more important.

Figure 7 is an external view of forward connector 116 of ECU 100 and includes a table showing pin number, circuit description and wire coloring code for connector 116. Coding of the 24 pins 151 labeled 1 through 24 in Figure 7 in connector 116 is merely an exemplary embodiment and not the only coding which may be used. Pins 151 could be smaller than shown and could be electrically spaced to prevent cross signals and cross currents. Connector 116 has a plurality of pins positioned in two parallel arrays 152, 154 of 12 pins each, commonly located within a rectangular wall shield 156, but other arrangements could be utilized. For example, pins 151 and shield 156 could be located on the wiring and corresponding sockets located in ECU 100.

Figure 8 is an external view of rear connector 118 of ECU 100. Fig 8 includes a table showing pin number, circuit description and wire coloring code for connector 118. It will be appreciated that coding of the 24 pins 157 labeled 1 through 24 in Figure 8 in connector 118 is merely a preferred embodiment and not the only coding which may be used. Pins 157 could be smaller than shown and could be electrically spaced to prevent cross signals and cross currents. Further, while connector 118 is shown as being a plurality of pins 157 positioned in two parallel arrays 158, 160 of 12 pins each, commonly located within a rectangular wall shield 162, other arrangements could be utilized. For example, pins 157 and shield 162 could be located on the wiring and corresponding sockets located in ECU 100.

Figure 9 is a block diagram illustrating ECU 100. Figure 9 is laid out in logic sequence showing portions that are contained within ECU 100 and the portions that are outside of ECU 100. Specifically, sensors such as water temperature sensor 126 and throttle position sensor 110 and various other sensors in powerhead 102 and elsewhere in engine 101, collectively referred to as box 164 are outside of ECU 100.

10

15

20

The signals from sensors 164 are connected through the electrical wiring harness connectors to input circuits 168 within the ECU 100. In addition to sensors 164 located outside ECU 100 are various sensors located inside ECU 100, which are collectively numbered 166, and which were previously exemplified by sensors 139. Sensors 166 are also connected to input circuits 168. Input circuits 168 perform certain receiving, conversion and other functions with respect to those sensors and generate output data that is fed to control circuits 170. Circuits 170 analyze output data from input circuits 168 and generate control signals to various circuits within ECU 100. Some of these various circuits which receive control signals from control circuits 170 are field injector output drive circuits 172, oil pump output drive circuits 174 and ignition circuits 178. Of particular note is that ignition circuits 178 are located within ECU 100, which is in contrast to prior art. This is allowed, in part, by water-cooled nature of ECU 100, such as is exemplified by presence of water passage 134 in heat transfer adjacency to ECU 100. Circuits 178 have ability to determine whether or not ignition coils have fired, since circuits 178 are within ECU 100 and are thus microprocessor based. This is in contrast to prior art ECUs which placed the ignition circuit outside of ECU 100 and thus did not allow such verification of firing. Fuel injector output drive circuits 172 receive control signals from control circuits 170 and transmit operational signals to fuel injectors 176. Oil pump output drive circuits receive control signals from control circuits 170 and transmit operational signals to oil pump 180. Ignition circuits 178, similarly, receive control signals form control circuits 170 and selectively allow ignition power to ignition coils 182, which, in turn, provide high voltage current at precise intervals to spark plugs 184 to generate ignition sparks which power engine 101.

25

30

Figure 10 is a block diagram illustrating a power distribution panel 186 for ECU 100 and includes a table listing electrical circuitry wiring of panel 186. Panel 186 includes various relays, uses and color-coded wiring. Many of these are connections to parts of engine 101 other than ECU 100 and will thus be mentioned only by noting that they are listed in the table in Figure 10. It will be understood that Figure 10 is provided primarily for purposes of background information and

1.0

15

20

25

enablement and not as any kind of limitation. Panel 186 can include any desired number and type of power connections or components. Panel 186 includes a 12 volt supply 188 to ECU 100 through a fuse 192, a switched 12 volt connection to ECU 100, a 26 volt supply 194 to ECU 100, an ECU connection 1008 to the fuel pump relay, and any other signal which is needed to power engine 101 under the direction of ECU 100.

Figure 11 is a block diagram of sensor and circuit switches included within external portion 196 of the sensing and switching system for engine 101 with which ECU 100. Figure 11 shows switches and sensors that are external to ECU 100 of Figure 3-6. Figure 11 shows sensors 164 that are connected through front electrical wiring harness connector 116 to input circuits 168 in ECU 100. It is preferable to use a separate wiring harness connector for the sensors/switches and the command controls/power signals. Among the sensors and switches in Figure 11 are water temperature sensor 198, water temperature switch 200, shift interrupt switch 202, crankshaft position sensor 106, rectifier/regulator 204, capacitor 104, power distributions panel 186, diagnostic connector 206, 208, throttle position sensor 134, air temperature sensor 210 and an oil pressure switch 212. The color coding of wiring used to interconnect these circuits and ECU 100 are listed in a table below Figure 11 for correspondence with coding shown in Figure 7 and Figure 8. As noted previously, there is no particular magic to color-coding used, except that it is intended to make repair jobs easier for repairmen. In this regard, special attention is directed to diagnostic connector 206, 208 that connects to ECU 100 and thereby to start a diagnostic routine within ECU 100 and also connects to a diagnostic unit (not shown) such as might be used by a repairman. A legend is included with Figure 11 in order to identify various sensors and switches which are shown on Figure 11.

Air temperature sensor 210 monitors temperature of air entering an air silencer. Sensor 210 is a positive temperature coefficient thermistor. A thermistor, as used herein, is a resistor whose resistance changes with temperature and alters voltage values accordingly. When temperature increases both resistance and voltage also

increase. When temperature decreases, resistance and voltage likewise decrease. Sensor 210 receives a voltage signal from ECU 100, another wire provides a ground circuit back to ECU 100. ECU 100 uses this signal to adjust air/fuel ratio in accordance with changes in incoming air temperatures. If sensor 210 senses values out of limits, or sensor 210 or its circuit fails, ECU 100 will store a service code and turn on the "CHECK ENGINE" light.

Water temperature switch 200 is located in starboard cylinder head (shown below). Switch 200 threads into a seat (not shown) in the water passage of the starboard cylinder head, but does not actually contact water. Switch 200 monitors water temperature to protect against an engine overheating. Its operation differs somewhat from the water temperature sensor 198 in that switch 200 is an on/off switch, not a thermistor. Switch 200 receives a voltage signal from ECU 100, and if powerhead temperature exceeds switch limits, a circuit grounds and ECU 100 will initiate SLOW, store a service code, and turn on a "WATER TEMP" light.

15

20

25

10

5

The water temperature sensor 198 is located in the port cylinder head (shown below.) It threads into a seat in the water passage of the head, but does not actually contact the water. The sensor has a dual purpose; it provides data to ECU 100 primarily for use in adjusting the air/fuel ratio during engine warm-up, and it will trigger the "system check" warning gauge when engine 101 overheats. The water temperature sensor is also a positive temperature coefficient thermistor, a resistor whose resistance changes with temperature. When temperature increases, both resistance and voltage also increase. Sensor 198 receives a voltage signal from ECU 100, and another wire provides a ground circuit back to ECU 100. ECU 100 uses this signal to adjust the air/fuel ratio in accordance with changes in powerhead water temperature. If sensor 198 senses values are above the limits, indicating an engine over heat condition, ECU 100 will initiate SLOW, store a service code, and turn on a "WATER TEMP" light.

10

15

20

25

The shift interrupt switch, which is used for six-cylinder engines only, is in contact with a shift lever. The switch is normally open. When the button is depressed (by excessive shift loads), the switch is closed and completes a ground circuit. ECU 100 momentarily shuts off fuel and spark to three cylinders (for example, Nos. 2,4,6) to momentarily reduce drive train loads and ease shifting, then automatically restores normal engine operation. The signal threshold can be, for example, 2144 RPM and the shift interrupt function will not work above it. Switch 202 must be released to its normally open position before the interrupt circuit can be actuated again. ECU 100 provides a voltage signal to the shift interrupt switch; another wire connects the switch to a powerhead ground. If the switch or its circuit fails, ECU 100 will store a service code and turn on the "CHECK ENGINE" light.

The throttle position sensor 134 is a rotary potentiometer located near flywheel cover 103, and contacts a vertical throttle shaft. Sensor 134 receives a voltage signal from ECU 100. As the throttle lever is rotated, ECU 100 receives a return voltage signal through a second wire. This return voltage signal is relative to the position of the throttle shaft. As the throttle opens, voltage increases. As the throttle closes, voltage decreases. A third wire completes the ground circuit back to ECU 100. If sensed values are out of limits, or sensor 134 or its circuit fails, ECU 100 will turn on the "CHECK ENGINE" light, store a service code, and automatically reduce engine speed to idle. Once a throttle position circuit fault has been detected by sensor 134 and ECU 100, engine 101 will not accelerate above idle speed. To reset, engine 101 must be stopped and the fault corrected.

The crankshaft position sensor 106 is an electro-magnetic device that generates a magnetic field that is interrupted by flywheel encoder ribs passing through it. This produces an alternating current voltage signal directly related to flywheel speed. Crankshaft top dead center position is determined by encoder rib spacing. Sensor 106 feeds the flywheel encoder data to ECU 100, which calculates timing position and engine speed. ECU 100 generates a tachometer signal, and controls fuel injector and ignition operation. Sensor 106 is located adjacent to flywheel cover 103

10

15

20

25

and, for example, requires a 0.050 plus or minus 0.005 inches (1.27 plus or minus 0.127 mm) sensor-to-flywheel air gap to operate properly. If sensor 106 fails, engine 101 will not run. If the air gap is incorrect, engine 100 will run erratically. A sensor 106 that is damaged or out of adjustment will cause ECU 100 to turn on the "CHECK ENGINE" light and store a service code, but only if the failure occurs while engine 101 is running.

Diagnostic connector 206 provides for a connection to a suitable computer having diagnostic software thereon, such as the proprietary OMC FFITM diagnostic software. The software allows a technician to do many useful things, such as actuate individual fuel injectors and spark plugs on individual cylinders, test oil injector operation, run the electric fuel circulation pump, perform cylinder drop tests, display real-time sensor values and system voltages, display switch conditions and engine operating parameters, verify engine and computer timing, retrieve and clear stored service codes, display accumulated engine hours, display recorded engine hours within six operational speed ranges, initiate a replacement powerhead oil break-in program, print and save the service report, install and service a replacement injector, and install and service a replacement electronic control unit. This software could also be designed to include any other desired service function, and is generally described here only for purposes of completeness. The specific diagnostic software is not part of the present invention, but is described in detail in a separate co-pending application.

Figure 12 is a block diagram of portion 214 of ignition circuit 178,182,184 of powerhead 102 which is external to ECU 100 and which connects to internal portion 178 of overall ignition circuit 178, 182, 184 for a four-cylinder engine. Portion 214 includes ignition coils 182 and spark plugs 184, although coils 182 are shown in more detail in Figure 12. Portion 214 connects primarily to connector 118, but also includes crankshaft position sensor 106, which is connected to input circuit 168 of ECU 100 through connector 116. The power connections to and from power distribution panel 186 are made through connector 118 to dual ignition coils 216, 218 for the cylinders as shown. Coils 216, 218 lead to spark plugs 220, 222, 224 and 226.

10

15

20

25

£ ...

Circuit 178, 182, 184 further includes a key switch 228 to provide security to the starting function of engine 101.

Figure 13 is a block diagram of portion 230 of another ignition circuit 178,182,184 of powerhead 102 102 which is external to ECU 100 and which connects to internal portion 178 for a six-cylinder engine. It will be understood that this ignition circuit 178,182,184 connects primarily to connector 118, but also includes crankshaft position sensor 106, which is connected is to input circuits 168 through connector 116. The power connections to and from the panel 186 are shown to be connected through connector 118 to the ignition coils 232, 234, 236, and 238. Coils 232, 234, 236, and 238 are, in turn, connected to spark plugs 240, 242, 244, 246, 248 and 250. A key switch 252 provides security to the starting function of engine 101.

Figure 14 is a block diagram of a fuel injector circuit 176 for a four-cylinder engine, showing connections to fuel injector output drives circuits 172 of ECU 100. As with the ignition circuit 178,182,184, power for operation of fuel injectors is provided by power distribution panel 186 through rear electrical wiring harness connector 118. Power is then provided within ECU 100 to fuel injector output drive circuits 172, and from circuits 172 out of ECU 100 through rear electrical wiring harness connector 118 to four fuel injectors 254, 256, 258 and 260 of circuit 176.

Figure 15 is a block diagram of a fuel injector circuit 262 for a six-cylinder engine, showing connections to fuel injector output drives circuits 172. As with the ignition circuit 178,182,184, power for operation of fuel injectors is provided by power distribution panel 186 through the rear electrical wiring harness connector 118 to fuel injector output drives circuits 172, and from circuits 172 back through rear electrical wiring harness connector 118 to six fuel injectors 264, 266, 268, 270, 272 and 274.

Figure 16 is a left, front, top exterior exploded perspective view of a portion of an outboard engine in partial cutaway to show one exemplary flow pattern for a coolant system 279 for cooling water flow through engine 101 when adapted for use

with ECU 100 of Figures 1-3. Cooling water enters lower unit 276 through water intake openings 278 and passes upwardly through lower unit 276 into a mid-section 280 into powerhead 102. This cooling water them circulates within powerhead 102 to cool appropriate components and then exits downwardly through mid-section 280 and out of water vents 282 or out of prop mounting cavity openings 284. This completes the water cooling circuit. The water will be circulated in powerhead 102 in the manner shown below in Figure 17. It will be recognized that although an outboard engine 101 is shown, and inboard or inboard/outboard engine could be substituted for engine 101. It will also be understood that the water may flow through the

10

15

5

Figure 17 is a flow diagram of the coolant flow system 286 of engine 101 connected to ECU 100 and the fuel supply connected to the fuel injectors in order to fuel engine 101. System 286 and the fuel supply/fuel return system 288 for a 4-cylinder engine would be similar for a 6-cylinder engine, except there would be additional fuel supply and return lines. In coolant system 279 and coolant system 286, water from the environment enters lower unit 276 via a port adapter 290 and to a water pump 279. From pump 279, water passes through a mid-section 280 into powerhead 102 to the inlet of a unit 292 through an inlet waterline 294. This coolant then flows from unit 296 through an outlet 297 and then through a coolant supply line 298 to the inlet 136 of water passage 134, through water passage 134, out of the outlet 138, and then on through a cooling water drain line 300 and then back to the environment through the lower unit 276. This cools at least a portion of ECU 100.

20

25

Figure 17 also shows the fuel supply system 288. Fuel enters system 288 through the fuel supply hose 290 from a fuel tank 293 past a sensor 294 and a second fuel line 296 to a fuel regulator 298. The fuel then passes through the jacket of the unit 292 to a fuel pump 300. From the fuel pump 300, the fuel passes through a third fuel line 302 to a fuel distribution block 304, where it is divided into four supplies for four fuel injectors 254, 256, 258 and 260. Any excess fuel from the fuel injectors is returned via fuel return lines 306, 308, 310, 312 to a second fuel junction block 314. From this second fuel junction block 314 the fuel then returns through a return line

316 to the fuel regulator 298 to repeat the fuel supply cycle. Fuel return line 316 is provided with a test point 318 for purposes of verifying adequate fuel flow.

Figure 18 is a schematic drawing of the overall electric wiring system 186 for the engine 101 exemplifying how the main engine parts can be electrically connected. Power distribution panel 186 provides power for system 186. The sensor circuits lead to connector 116. Ignition circuit 216 is connected to ECU 100 through connector 118. Crankshaft position sensor 106 is part of system 186. Fuel injector circuits 176 appear, and fuel supply tank 293 is seen.

While the invention has been described in terms of various specific embodiments, those skilled in the art will recognize that the invention can be practiced with modification within the spirit scope of the claims.